



## Locked Conditions Cards

Locked Conditions cards are encoded with a start date and expiration date. The cards will only work within these dates.

**To use the Locked Conditions cards, follow this simple procedure:**

1. Press the Start button to begin a game, just like normal.
2. Carefully click through any ad screens or FACTS leaderboards, until you reach the How Many Golfers screen. Do NOT press Start on this screen.
3. On the How Many Golfers screen, swipe the Locked Conditions card.
4. The game will connect to ITNet to retrieve the Locked Conditions data. A blue screen will appear once this process is complete.
5. Press Start to go to the How Many Players screen. Look for the Locked Conditions icon in the lower right corner of the screen to verify that the game is in the correct mode. If you do NOT see the icon, swipe the card again.
6. From the How Many Players screen with the Locked Conditions icon showing, select the correct number of players on that machine and press Start.
7. Next select the course you wish to play.
8. Players should check in with their cards and pay for games as usual. Once all players are checked in, the game will start.

### **Notes:**

The game will end normally, and there is no extra delay or pause at the end of the match. If you are recording scores manually you will need to get to the machines quickly to write down the scores and tiebreakers. You should warn players NOT to press the buttons after the match, and to call a marshal over quickly to record the information.

The Locked Conditions cards for LIVE are basically creating a special contest that is expecting something like 256 players. This contest stays open until the leaderboard fills, or 7 days of inactivity occurs. It is best if you only use the Locked Conditions format for your qualifying rounds, and switch to prize or glory play for head-to-head matches. If you try to use locked conditions on a previously used course for later rounds, the conditions will be the same.

A Locked Conditions contest allows for a player to enter the same contest more than once, in case you ever need to restart a match.

Although the Locked Conditions cards are programmed with a start and end date, it is always best to keep these cards under careful supervision and not let them out of your control.